





FIG. 1


ROBIN MARK GROSER
of GROSER & GROSER
AGENT FOR THE APPLICANTS



ROBIN MARK GROSER
of GROSER & GROSER
AGENT FOR THE APPLICANTS

FIG. 2




FIG. 3


ROBIN MARK GROSER
of GROSER & GROSER
AGENT FOR THE APPLICANTS




FIG. 4A

FIG. 4B

ROBIN MARK GROSER
of GROSER & GROSER
AGENT FOR THE APPLICANTS




FIG. 5


ROBIN MARK GROSER
of GROSER & GROSER
AGENT FOR THE APPLICANTS

25a



F1

F2

F3

DEVICE NAME	CONNECTION	USED-BY TERMINAL
SCANNER	BLUETOOTH/LINK 1	FIRST TABLET TERMINAL
READER	USB/PORT 1	SECOND TABLET TERMINAL
DISPLAY	USB/PORT 2	NOT USED
CASH	SERIAL/PORT 3	NOT USED

FIG. 6


ROBIN MARK GROSER
of GROSER & GROSER
AGENT FOR THE APPLICANTS